

PowerCap® Active™

PRODUCT CODE: CAE601-941-100

THE POWERCAP® ACTIVE™ SYSTEMS ARE A LIGHTWEIGHT & ERGONOMIC SOLUTION ABLE TO WORK EFFICIENTLY IN VERY DUSTY ENVIRONMENTS

TECHNICAL SPECIFICATION

RESPIRATORY PROTECTION

INSTRUCTIONS FOR USE

The airflow of the unit should be checked prior to use

Fit cap on head and fasten strap to ensure the correct fit

For adequate respiratory protection this cap must be worn with the peak facing forward and adjusted to the size of the user's head

To remove saturated filters unscrew each filter and remove all parts and dispose of them

To fit new filters align the fittings on the filter with those on the filter housing. Push fit and tighten

Care must be taken to ensure that the correct respiratory protection device is selected for the work to be carried out. If in doubt seek professional advice

CLICK HERE

To learn more about the innovative Powercap®



PERFORMANCE

PowerCap unit gives a cooling, comfortable supply of filtered air at 160L/Min. Equivalent to FFP2. APF=10

FaceShield protects the user from Medium Energy, High Speed Particles, Dust and Liquid Droplets Cap

Cap protects the user against bumps and scrapes

CLEANING & MAINTENANCE

The plastic parts can be cleaned with a damp cloth. Chemical or abrasive cleaners should not be used

The cover can be brushed clean. Do not immerse the unit in water

The unit should be stored out of direct sunlight, away from chemicals and not exposed to extremes of temperature

FILTER:

High efficiency sub-micron particulate filters with High Impact Polystyrene front and back



IMPELLER:

ABS
(Acrylonitrile Butadiene Styrene)



CAP:

Lint Free Textile Cap with rigid drive-unit fixings

FACESHIELD:
Polycarbonate

FACESeal:
Foam with brush nylon covering

POWERCAP®
Active™

CONFORMITY

Meets the requirements of: EN 12941:1998 TH1 as a Respiratory Protective Device

FaceShield: EN166:1995 1.3.B (IP Version only)

Hardcap: EN 812:2001 A1

PowerCap® Active™

PRODUCT CODE: CAE601-941-100

THE POWERCAP® ACTIVE™ SYSTEMS ARE A LIGHTWEIGHT & ERGONOMIC SOLUTION ABLE TO WORK EFFICIENTLY IN VERY DUSTY ENVIRONMENTS

**TECHNICAL
SPECIFICATION**

RESPIRATORY PROTECTION

DIMENSIONS OF OUTER PACKAGING

Quantity: 1

Weight: 1.5kg (Approx)



HEIGHT:
266mm

WIDTH:
185mm

LENGTH:
320mm

DIMENSIONS OF CAP

Lite:

Comes with Charging Station, Charger and Storage Container

Product Weight: 680g (835g with Charger and Dock)

IP Lite:

Comes with Charging Station, Charger and Storage Container

Product Weight: 720g (875g with Charger and Dock)



FEATURES & BENEFITS

Battery Pack and Motor Unit can now be easily removed from the Cap for machine washing

PowerBox Battery Pack is user replaceable for shifts longer than 8 hours (spare PowerBox required)

PowerBox Battery Packs are now available as user friendly spares

PowerStation Charging Dock facilitates easy charging

LIMITATIONS OF USE

Protection will only be offered if the PowerCap® Active™ is fitted correctly

The cap, when in contact with the skin may cause allergic reactions to susceptible individuals. If this occurs leave the hazard area, remove the mask and seek medical advice

This product is a respiratory protection device only

Check airflow with the Test Unit before use. Re-test outside of area of use at regular intervals to ensure flow level

Use in well-ventilated areas only, which are not deficient in oxygen and do not contain explosive atmospheres

Ensure the foam skirt is fitted neatly around the face before entering the hazard area

Do not use where exposure to chemical gases may be

The use by date of the filter is printed on the outside of the cartridge

The working life of the filters depends on many factors including work rate, airflow and concentration of any contaminant in the atmosphere

Only JSP PowerCap Lite® filters can be used as replacements

To obtain maximum workable life from the unit, allow the battery to run down fully before recharging

